



### Construction and Finish

- The Essential Series Planters are available in a ASTM A606 Type 4 Cor-Ten® Steel option. Planters are offered in two finish options:
  - Initial flash for on-site weathering; no exterior sealant
  - Pre-flashed and weathered with exterior sealant
- Planters are sealed internally with a waterproof sealant along all seams and welded areas only, and are manufactured with standard 1", 1.5", 2" drain holes or no drain holes.
- Planters do not weather with consistent color and patina among groups. Units weather at varying rates and develop coloration which is unique to each individual unit.

### Transport and Installation

- Due to nature of this material, great care should be taken in moving, transporting, and installation to **avoid scratching/rubbing of the exterior and dragging of planter base** on cement or other substrate. Scratching or excessive rubbing can "open" areas to re-oxidation which may temporarily leach onto adjacent surfaces and substrate.
- Planters should be kept in an upright position and are best transported using wood pallets with pallet trucks or a forklift for greater distances.

### Cleaning and Maintenance

- Planters can be cleaned using a low to moderate water flow with soft cloth. Do not use wire brushes or high-pressure washers. Excessive rubbing may disturb surface and "open" metal to re-oxidation.



### Size and Capacity - Cor-Ten® Steel

style	l x w x h	capacity	avg weight
ES_40C	26" x 26" x 40"	93 gal./12.43 ft3	96 lbs
ES_30C	30" x 30" x 30"	77 gal./10.29 ft3	86 lbs
ES_24C	48" x 24" x 24"	105 gal./14 ft3	92 lbs
ES_18C	30" x 30" x 18"	66.5 gal./8.69 ft3	63 lbs
ES_14C	42" x 42" x 14"	91 gal./12.16 ft3	91 lbs
ES_14.2C	26" x 26" x 14"	28 gal./3.74 ft3	45 lbs